


## Open SetApp and click on the 3 dots

## Scan QR Code


Scan the QR code located on the device's ratings label. Show me what to scan


Commissioning

View Only



Other Options to Enter QR Code





If this does not say "Fixed" – user should exit the app, enable location services via the phone settings, and launch the app again